



Rocky Mountain
WESTY

970-310-3441

Fort Collins, CO

Locking Storage Box Installation Guide

Rocky Mountain Westy Inc.

172 Spaulding Lane

Fort Collins, CO 80524

970-310-3441

www.rockymountainwesty.com





Start your installation by placing your new locking storage box in place behind the passenger seat pedestal. Make sure you have good alignment at the “B” pillar and where the side of the box meets the seat pillar side.





After you have double checked your box alignment, mark all the holes to be drilled with a black marker by marking the floor and the single hole in the “B” pillar through the mounting tabs.





Remove the box and drill all the mounting holes through the floor mat into the wood subfloor, and the single mounting hole in the “B” pillar. Make sure you use the correct drill bit for the mounting screws you intend to use to fasten the box down.





Set the locking storage box back in place and install all mounting screws through the mounting tabs into the floor and in the “B” pillar. Be careful not to overtighten the screws.



To set your new Combi-Cam lock to your desired 3 digit combination, simply slide a paper clip into the hole on the side of the knob while the lock is set to all zeros. While the wire is inserted, choose your personal combination and pull the paper clip wire out. That’s all there is too it. If you ever want to change your combination, just enter your current combination, slide a paper clip into the hole, select your new code and pull the wire out.